

Lexmark T640/644 and similar models

Investigation by Delacamp has shown that the pressed steel-type doctor bar (1. picture) which is used in newer Lexmark T640/644 cartridges can cause problems when used with aftermarket toners. In some cases this type of doctor bar can cause toner smear at the developer roller and lead to defective printouts. Delacamp highly recommends the use either of cartridges which have the solid-type doctor bar (2. Picture) or to replace the pressed-steel type doctor bar with the solid doctor bar type (Delacamp Item 62541).

1. Picture



2. Picture

